



NOTES:

1. APPLY NOX-CRETE SILCOSEAL CLASSIC BOND-BREAKER BETWEEN SLAB AND WALL POURS.
2. THE PS=Ø RELIEF JOINT TO REMAIN OPEN FOR XX DAYS.
3. AFTER THE TIME PERIOD SPECIFIED ABOVE, THE PS=Ø COUPLERS AND JOINT TO BE GROUTED WITH BASF MASTERFLOW 885 HIGH-PRECISION, NONSHRINK METALLIC-AGGERATE GROUT.
4. SEE PS=Ø MANUFACTURE DATA FOR MORE INFORMATION.

PS=Ø RELIEF JOINT @ WALL